

READER DEFAULT CODE OBDII

Reference : AC 5247



Item name	READER DEFAULT CODE OBDII
Bar code	3700461494390
Introduction	Allows the reading and deletion of most basic defect codes (engine defects, pollutant emissions). Allows real-time control of ECU values.
Text	Uses the vehicle battery as a power source, so no internal battery is required
Specifications	Specifications: <ul style="list-style-type: none">- works on most vehicles (from 2001 (fuel) and 2003 (diesel) for European vehicles, and 1996 for American vehicles), which are compatible with OBD2 and CAN- retrieves vehicle information (based on VIN number), the device will work if the vehicle manufacturer has given access to diagnostic information- reads and clears generic and manufacturer-specific diagnostic trouble codes (DTCs)- turns off the engine light (MIL)- supports multiple fault code queries, including general, manufacturer-specific and pending codes- definitions of codes readable on the display- reviews live data and I/M status- determines the cause of the Check Engine Light (MIL)- easy to use with OBD2 cable- works safely with the vehicle ECU- reliable, safe and convenient in size- uses vehicle's own battery as a power supply so no internal batteries are needed

- 2" color display TFT, easy to read
- multi-language: EN, FR, DE, ES, IT, PT, FN, NL
- dimensions: 124x72x18mm
- weight: 180g

Warranty period 2 years

Tariff code Tariff Normal (TN)

Warranty Procedure DIAGNOSTIC



***Public price Exl. Tax : €59.00**

*Applicable user fees from 01/09/2024 to 31/08/2025

CLAS EQUIPEMENTS
83, chemin de la CROUZA
73800 CHIGNIN
France

Tel : +33 (0) 4 79 72 62 22
Fax :

Monday to Friday - From 8 to 12h30
and from 14h to 17h30 (16h30 on
Friday)